


V40N / V40NT



| | | | | |
|----|---------------|-----------------------------|----|-------|
| | Z645CR | Opening push button chromed | \$ | 5,00 |
| 9 | Z109 | Long bolt springs | \$ | 2,00 |
| 10 | Z106 | Bolt | \$ | 11,00 |
| 11 | Z590R | Pin. Medium, 2 pcs. | \$ | 3,00 |

| | | | | |
|----|---------------|--|----|-------|
| 12 | Z115R | Stop bag opening yarn, 2 pcs. | \$ | 3,00 |
| 13 | SL101 | Security Lock key, including bush and under lock platelets | \$ | 19,00 |
| 14 | Z4512R | Plate below lock for Security Lock key | \$ | 2,75 |